


PLASTI-CHEMIE

North America LLC

Crack Treatment

1.  crack

2.  cut the crack

3.  cut the cracks in angle 45°

4. 

clean it and prime it, put stainless fibers in the angled cracks before priming



waved stainless steel fiber